

音色

音色选择



双音色平衡

双音色演奏功能开启

双音色音量平衡复位

双音色平衡一

双音色平衡十

延音共振
(仅适用于三角钢琴、大钢琴、柔和三角钢琴、现代钢琴)

关闭 开启

小 中 大

琴键力度

关闭 轻 中 重

明亮度
(-10 ~ +10)

关闭 - +

混响

关闭 开启

声音效果

干净 饱满 忧伤 丰富多彩 历史性

耳机声音效果

关闭 向前 标准 广阔

A°0		C°1			D°1			F°1			G°1			A°1			C°2			D°2			F°2			G°2			A°2			C°3			D°3			F°3			G°3			A°3			C°4			D°4			F°4			G°4			A°4			C°5			D°5			F°5			G°5			A°5			C°6			D°6			F°6			G°6			A°6			C°7			D°7			F°7			G°7			A°7			C8		
A0	B0	C1	D1	E1	F1	G1	A1	B1	C2	D2	E2	F2	G2	A2	B2	C3	D3	E3	F3	G3	A3	B3	C4	D4	E4	F4	G4	A4	B4	C5	D5	E5	F5	G5	A5	B5	C6	D6	E6	F6	G6	A6	B6	C7	D7	E7	F7	G7	A7	B7	C8																																																										
三角钢琴		大钢琴			柔和三角钢琴			现代钢琴			古典电钢琴			现代电钢琴			爵士风琴			教堂风琴			羽管键琴			电颤琴			弦乐合奏			慢弦乐			合奏			幻想音 1			幻想音 2			房间			休息厅			小型音乐厅			大型音乐厅			现场音乐厅			大教堂			标准			无音效			强烈共鸣			轻微共鸣			柔和			明亮			标准			开放式			半开放式			封闭式			入耳式			耳塞式														
音色选择																																																																																																													

节拍器

节拍器



节拍器拍号

1/4 2/4 3/4 4/4 5/4 3/8 6/8 - +

节拍器音量

降低节拍速度 (-2)

提高节拍速度 (+2)

A°0		C°1			D°1			F°1			G°1			A°1			C°2			D°2			F°2			G°2			A°2			C°3			D°3			F°3			G°3			A°3			C°4			D°4			F°4			G°4			A°4			C°5			D°5			F°5			G°5			A°5			C°6			D°6			F°6			G°6			A°6			C°7			D°7			F°7			G°7			A°7			C8		
A0	B0	C1	D1	E1	F1	G1	A1	B1	C2	D2	E2	F2	G2	A2	B2	C3	D3	E3	F3	G3	A3	B3	C4	D4	E4	F4	G4	A4	B4	C5	D5	E5	F5	G5	A5	B5	C6	D6	E6	F6	G6	A6	B6	C7	D7	E7	F7	G7	A7	B7	C8																																																										
1		2			3			4			5			6			7			8			9			0			Grave			Largo			Lento			Larghetto			Adagio			Adagietto			Andante			Andantino			Maestoso			Moderato			Allegretto			Animato			Allegro			Vivace			Presto			Vivacissimo			Prestissimo																																
节拍速度数值 输入用数字键盘 (3 位数输入)																																																																																																													
节拍器速度 (音乐用语)																																																																																																													

音乐会魔法

演示

教程



选择乐曲

I'm A Little Teapot 2

Old MacDonald Had A Farm 5

Row, Row, Row Your Boat 7

Deck The Halls 10

We Wish You A Merry Christmas 12

Joy To The World 14

Londonerry Air 17

Auld Lang Syne 19

When The Saints Go Marching In 22

Fur Elise 26

William Tell Overture 24

Blue Danube Waltz 29

Waltz Of The Flowers 31

Pomp And Circumstance 34

Chopineses 36

Funiculì Funiculà 38

音乐会魔法演示模式

分类播放

随机播放

A°0		C°1			D°1			F°1			G°1			A°1			C°2			D°2			F°2			G°2			A°2			C°3			D°3			F°3			G°3			A°3			C°4			D°4			F°4			G°4			A°4			C°5			D°5			F°5			G°5			A°5			C°6			D°6			F°6			G°6			A°6			C°7			D°7			F°7			G°7			A°7			C8		
A0	B0	C1	D1	E1	F1	G1	A1	B1	C2	D2	E2	F2	G2	A2	B2	C3	D3	E3	F3	G3	A3	B3	C4	D4	E4	F4	G4	A4	B4	C5	D5	E5	F5	G5	A5	B5	C6	D6	E6	F6	G6	A6	B6	C7	D7	E7	F7	G7	A7	B7	C8																																																										
1		3			4			6			8			9			11			13			15			16			18			20			21			23			25			27			28			30			32			33			35			37			39			40																																									
选择乐曲																																																																																																													

设置

程序变更编号发送
关闭 开启

多音色模式
关闭 开启

蓝牙
关闭 开启

MIDI 通道
2 4 7 9 11 14 16

调音 (427Hz ~ 453Hz)
440 Hz -0.5 Hz +0.5 Hz

移调 (-6 ~ +5)
关闭 开启 - +

程序变更编号发送用数字键盘 (3 位数输入)
1 2 3 4 5 6 7 8 9 0

MIDI 通道
1 3 5 6 8 10 12 13 15

小音量平衡
关闭 类型 1 类型 2 类型 3 类型 4 类型 5

调音数值输入用数字键盘 (3 位数输入)
1 2 3 4 5 6 7 8 9 0

自动关机
关闭 15 分钟 60 分钟 120 分钟

本地控制

教程功能

〈选择乐谱, 乐曲〉

教程

乐谱选择用数字键盘
A0 B0 C1 D1 E1 F1 G1 A1 B1 C2 D2 E2
1 2 3 4 5 6 7 8 9 0

上 下
一首 一首

〈选择教程乐曲声部〉* 需要事前选择教程乐曲

左手
按一次
仅左手演奏声部

右手
按两次
仅右手演奏声部

两手
按三次
左手和右手演奏声部

〈播放教程乐曲〉

演奏 教程
音乐会魔法
开始/停止 录音
音量器
设定

录音器

〈开启乐曲录音器〉

① 进入录音模式

② 选择录音乐曲号码

③ 开始录音

〈播放录音乐曲〉

乐曲内存
乐曲 1 乐曲 2 乐曲 3

〈删除全部录音乐曲〉

① 同时按下
② 开启电源